

B.Tech Project Presentation

Pulse Electrodeposition of CuO/Cu₂O on 3D-Printed Nickel-Containing Carbon Structures for Visible-Light-Driven Photocatalytic Degradation of Methylene Blue

Presented by:
Ojasvi Pandey(B22ME043)
Nikita Sewda(B22ME042)



Department of Mechanical Engineering
Indian Institute of Technology, Jodhpur

Motivation


In India , 820 million people face high to extreme water stress

200,000 Indians die annually due to inadequate water quality

By 2030, 700 million people could be displaced due to water scarcity

The Hidden Poison: Methylene Blue Contamination

- Tissue necrosis (the death of body tissue)
- Cyanosis (oxygen deprivation causing Blue skin discoloration)
- Respiratory distress
- Cardiovascular complications
- Vomiting
- Jaundice
- Neurological damage
- Carcinogenic
- Mutagenic
- Highly toxic



Visual representation of the textile industry's massive water consumption and pollution footprint in India

Objective

To compare the photocatalytic performance of 3D-PEGDA/x%Ni_xCu₂O and 3D-PEGDA/x%Ni_xCu₂O_Ag microlattice structures for efficient degradation of methylene blue in water.

Advantages pyrolytic carbon structure designed as a microlattice

- The microlattice design allows UV light to penetrate deep into the 3D-PEGDA/x%Ni_xCu₂O_Ag structure, maximizing photon absorption and uniform ROS generation.
- Its 3D porous geometry offers a high surface area for greater catalyst loading and more active sites, enhancing pollutant degradation efficiency.

Sources :

[Source 1](#)


[Source 2](#)

[Source 3](#)

[Source 4](#)

[Source 5](#)

[Source 6](#)



Photocatalytic Breakdown Process

1) Photon absorption – generating charge carriers:



2) Charge separation & transfer (role of Ag NW and PyC):



$e^- (\text{CB}, \text{Cu}_2\text{O}) \rightarrow e^- (\text{Ag or PyC})$ (electron transfer to Ag or PyC)

$\text{Ag} + h\nu \rightarrow \text{Ag}^*$ (hot electron) \rightarrow inject e^- (plasmonic hot-electron injection; optional extra path)

3) Oxygen reduction \rightarrow superoxide radical




4) Protonation / disproportionation \rightarrow hydroperoxyl ($\text{HO}_2\bullet$) and hydrogen peroxide (H_2O_2)



5) Hydrogen peroxide \rightarrow hydroxyl radical

Two main routes:

Reduction by electron:




Photolysis (light-induced):



6) Catalyzed decomposition on metal surfaces:


$\text{H}_2\text{O}_2 \rightarrow 2 \bullet\text{OH}$ (Ag surface may catalyze decomposition under certain conditions)

Direct hole oxidation (alternate path):




7) Overall pollutant oxidation / mineralization

Representative overall step:




Preparation of samples

Design and Fabrication




Electrochemical Deposition



Parameters-
Frequency- 50Hz
Voltage- 5V
Duty Cycle- 40%

Electrolyte Composition-
NaOH - 1.6%
 $\text{CuSO}_4 \cdot 5\text{H}_2\text{O}$ - 0.75%
Lactic acid - 3.9%


Drop Casting



Characterization


SEM

SEM is used to study the surface morphology and microstructural features of the microlattice. It provides general insights into the overall structure, including the deposition and distribution of Cu₂O and Ag on the pyrolytic carbon surface.




FESEM

FESEM is also used to study the surface morphology and microstructural features, offering higher resolution and clearer surface details compared to conventional SEM. This allows for a more precise analysis of the deposition and distribution of Cu₂O and Ag on the pyrolytic carbon surface.




EDS

EDS (Energy Dispersive X-ray Spectroscopy) is used to determine the elemental composition of a material and to confirm the presence and distribution of elements like Cu, O, Ag, Ni, and C in the synthesized photocatalyst.



XRD


XRD (X-ray Diffraction) is used to identify the crystalline phases present in a material and to determine its crystal structure, purity, and average crystallite size, confirming the formation of compounds like Cu₂O and Ag on the pyrolytic carbon framework.



Characterization


✓ Raman Spectroscopy

Raman Spectroscopy is a non-destructive technique used to characterize the chemical structure and molecular vibrations of the material. For the Cu₂O and Ag deposited on the pyrolytic carbon microlattice, it specifically helps to identify the different phases present (e.g., confirming Cu₂O and Ag particles) and provides crucial structural insights.






✓ UV-Vis Spectroscopy

UV-Vis Spectroscopy is used to study the optical properties of the photocatalyst, such as light absorption and band gap energy, helping to evaluate its photocatalytic efficiency and ability to absorb UV or visible light for dye degradation.









Sample









SEM







3D-PEGDA/0.5Ni_xCu₂O









100x
3D-PEGDA/1Ni_xCu₂O









3D-PEGDA/5Ni_xCu₂O









3D-PEGDA/10Ni_xCu₂O









3D-PEGDA/0.5Ni_xCu₂O_y-Ag



3D-PEGDA/1Ni_xCu₂O_y-Ag













3D-PEGDA/5Ni_xCu₂O_y-Ag




2500x

3D-PEGDA/10Ni_xCu₂O_y-Ag




EDS

3D-PEGDA/0.5Ni_xCu₂O




3D-PEGDA/1Ni_xCu₂O




EDS


3D-PEGDA/0.5Ni_Cu₂O_Ag




3D-PEGDA/1Ni_Cu₂O_Ag







3D-PEGDA/5Ni_Cu₂O_Ag







3D-PEGDA/10Ni_Cu₂O_Ag







3D-PEGDA/0.5Ni_xCu₂O






3D-PEGDA/1Ni_xCu₂O




3D-PEGDA/5Ni_xCu₂O




3D-PEGDA/10Ni_xCu₂O




3D-PEGDA/0.5Ni_Cu₂O_Ag




3D-PEGDA/1Ni_Cu₂O_Ag



3D-PEGDA/5Ni_Cu₂O_Ag




3D-PEGDA/10Ni_Cu₂O_Ag



Looking at the EDS color mapping, it is clear that Cu deposition is highest in the 5% Ni sample.

The Cu signal appears denser and more uniformly spread at 5% Ni compared to 0.5%, 1%, and 10% Ni.

XRD



◆ Cu₂O Formation

- XRD shows strong reflections at $\sim 30^\circ$, 36° , 42° , 62° , 73°
- These match standard Cu₂O peaks → confirms Cu₂O deposition on all samples


◆ Ag Detection

- Additional peaks appear around 38° , 44° , 64° only in Ag-coated samples
- Low intensity → Ag deposited in small amount or finely dispersed

◆ Influence of Ni Content

- As Ni increases, peaks become sharper and more defined
- Indicates better crystal growth and higher structural order

Raman Spectroscopy



The symmetric stretching of oxygen atoms in the cuprite crystal lattice produces a Raman-active vibrational mode that is highly ordered and strong, appearing around $\sim 150 \text{ cm}^{-1}$. Therefore, the peak observed at $\sim 147 \text{ cm}^{-1}$ confirms the presence of Cu₂O.

We observe that as Ni increases, Cu₂O formation increases up to 5% Ni and then decreases at 10%.

This is reflected by the highest Raman intensity at 5% Ni, followed by a clear drop at 10% Ni.

Observation

CuO/Cu₂O 5 Ni sample

T = 30 Min T = 60 Min T = 90 Min T = 120 Min T = 150 Min T = 180 Min



Reduction in MB Concentration

CuO/Cu₂O 5 Ni sample
with Ag

T = 30 Min T = 60 Min T = 90 Min T = 120 Min T = 150 Min T = 180 Min



Observation

- From SEM we can observe that Cu_2O appears as a rough, granular coating on the PyC struts, forming small clustered deposits that clearly indicate successful nucleation and surface coverage.
- Ag nanowires or **thin flake-like features are clearly visible** decorating the Cu_2O layer, especially around the joints and intersections of the struts.
- Among all samples, the **5% Ni sample shows the highest and most uniform Cu-based deposition**, as seen from the denser Cu distribution and stronger structural signals compared to 0.5%, 1%, and 10% Ni.
- The crystalline features associated with Cu_2O are strongest at 5% Ni, indicating that this **Ni content promotes better nucleation and growth of Cu_2O** , while 10% Ni causes a decline due to unstable deposition conditions.
- A clear Raman peak around $\sim 147\text{--}150 \text{ cm}^{-1}$, arising from symmetric stretching of oxygen atoms in the cuprite lattice, confirms the presence of Cu_2O , and the intensity of this peak is also highest at 5% Ni.
- All characterization techniques consistently show a trend: **Cu_2O formation increases from 0.5% → 1% → maximum at 5% Ni, followed by a drop at 10% Ni**, indicating an optimal Ni level for stable and uniform oxide growth.
- This trend directly reflects in performance, with the **5% Ni sample showing the maximum Methylene Blue degradation**, correlating with its highest Cu_2O loading, best crystallinity, and most uniform surface coverage.

Conclusion

Cu₂O Deposition Increases Progressively from 0.5% to 5% Ni

- As Ni content increases from 0.5% to 5%, Cu₂O deposition increases steadily because the surface gains more Ni sites that improve electron-transfer efficiency.
- More Ni provides additional high-energy nucleation sites, allowing Cu₂O crystals to start forming more easily and in larger numbers.
- Ni helps maintain a more stable local pH during electrodeposition, which supports proper Cu₂O growth instead of patchy or discontinuous films.
- Together, these effects lead to faster Cu²⁺ reduction, higher nucleation density, and more uniform Cu₂O crystal growth, resulting in maximum Cu₂O deposition at 5% Ni.

Conclusion

Cu₂O Formation Drops at Higher Ni Content

Reasons

1) High Ni makes the surface too conductive

- Fast electron flow pushes the potential very negative.
- This favors Cu²⁺ → Cu⁰ (metal), not Cu₂O formation. But metallic Cu does not deposit uniformly → overall Cu deposition decreases.

2) Ni catalyzes the Hydrogen Evolution Reaction (HER)

Reaction: H⁺ + e⁻ → H₂

- HER competes with Cu deposition.
- H₂ bubbles block the surface → Cu ions can't reach the surface properly.

Result → reduced Cu deposition.

3) Local pH becomes unstable near the surface

HER increases OH⁻ concentration suddenly.

The unstable pH conditions disrupt Cu₂O formation.

Instead of depositing, some Cu redissolves or forms uneven spots → less net Cu deposited.

So,Cu₂O deposition increases steadily from 0.5% to 5% Ni due to improved nucleation and electron transfer, but drops at 10% Ni because excessive Ni disrupts stable Cu₂O growth.

Conclusion

- Among all the samples tested, the composite containing 5% Ni exhibited the highest photocatalytic activity, showing the most visible and significant degradation of methylene blue. This indicates that 5% Ni loading provides the optimum balance between active surface sites and charge-transfer efficiency, leading to enhanced dye breakdown under the given experimental conditions.
- There was no significant visible difference in the cleaning efficiency between samples prepared with Ag and those without Ag. Since Ag was drop-casted, the deposited material dissolved immediately upon contact with the solution, preventing any meaningful comparison of their surface-assisted degradation performance.